

Foam Flyers

Clean Styrofoam trays or Card
Pencil



Tape
Bendy straw or Straw

Elastic band
Scissors

Draw around the template onto a clean Styrofoam tray or card.

Cut out carefully.

Make two extra cuts as shown along the edge of the wings (A).





Score along the dotted line for the tail stabilisers of the flyer.

Bend these upwards.

Tape a bendable straw to the bottom of the flyer so that the straw extends about 15 mm from the front of the plane


The bendy part of the straw must face downwards.

If you are using ordinary straws then fold the top of the straw over and staple just below the bend.



To launch the flyer, hook a rubber band around the tip of the bendy straw, as shown.

Hold the rubber band, gently pull back on the tail, aim up (away from people!), and let fly.



Foam Flyers

